Micro Pet™

Baby Dino Instructions

◇◇BABY DINO GAME◇◇

Remove the plastic tab to activate your Baby Dino.



SET THE TIMER

Press B to enter timer mode.
Press A to set the hours, B to set the minutes, C to start. Note: If you don't set time, you can't start the game.
Press B to go back to game mode.

Baby Dino will hatch in 5 minutes.
As soon as Baby Dino hatches, it will beep at you for attention.

Press A and C button together at the same time, and you will be able to select the sound on or off.

FEEDING

Press A to select the feeding icon on the screen.
Press B to confirm your selection.
Press A to select the proper food.....either meal , snack or water .
Press B to feed your Baby Dino.
Baby Dino won't be hungry for the next 2~5 hours after meal.
Baby Dino will get sick, if you over feed: 15 glasses of water or 15 pieces of snack within one day's time.

PLAY TENNIS

Guess which way Baby Dino will turn. There are 5 chances in each game to match Baby Dino. The more you match, the level of satisfaction will increase by a grade on the condition meter.
Press A to select play tennis icon on the screen.
Press B to confirm your selection.
Press A if you think Baby Dino will turn to the left.
Press B if you think Baby Dino will turn to the right.

MEDICINE

If appears, Baby Dino is sick and needs medicine.
Press A to select the medicine icon on the screen.
Press B for injection. Note: 2 or 3 injections are needed before Baby Dino is well.

EDUCATION

Baby Dino needs education when it makes noise for no reason - which means it's not hungry, sick or wanting to play games.
Baby Dino will be angry if education is given when not needed, this will effect its level of satisfaction.
Teacher's face will appear when education is correctly delivered.

PLAY POKER

Guess whether number is greater than seven or smaller than seven. There are 5 chances in each game. If Baby Dino wins the game, the level of satisfaction will increase by a grade on the condition meter.
Press A to select play poker icon on the screen.
Press B to confirm your selection.
Press A if you guess number is greater than 7.
Press B if you guess number is smaller than 7.

WEATHER

When the sun, snow or rain appear on screen, You must choose either hat , scarf or umbrella for your Baby Dino.
Weather will be changed 2~5 times everyday.
Press A to select weather icon on the screen.
Press B to confirm your selection.
Press A to choose: wear a hat when the sun comes out, wear a scarf when it snows, carry an umbrella when it rains.

CLEANING

Baby Dino goes to the bathroom every 1~4 hours. If droppings appear on the screen. You must clean it up right away, otherwise Baby Dino will get sick.
Press A to select sweep icon on the screen.
Press B to flush the screen.
Baby Dino will be very happy after the dropping are clean up.

CONDITION METER

To determine the mood, health, age, behavior of Baby Dino:
Press A to Select condition icon on the screen.
Press B to check the following:
Baby Dino's age and weight.
Discipline level, hunger and happiness .
For example: Stomach

LIGHT

Press A to select light bulb icon on the screen.
Press B to confirm your selection.
Press A to select the light either on or off.
The light should be turned off when Baby Dino is sleeping, or it might get restless.
Baby Dino will automatically turn the light on when it wakes up.

CALL SIGN

When this icon is highlighted, Baby Dino will beep you for attention.
Check condition meter to determine what Baby Dino needs. Maybe it is sick, hungry or in a bad mood.

AGES 8 AND UP

GROWTH INFORMATION

One day is equal to one year for Baby Dino.
Baby Dino will change appearance 4 times from age 0 to age 5. After 6 years old, 6 different shapes of dinosaur will appear based on how well you take care of it.
Note: Each time you hatch a New Baby Dino, it could grow up to be any one of the 6 different patterns.

BATTERIES

Replace the batteries if the LCD is weak.
Using LR44 battery. Be sure to use both new batteries, do not mix old and new batteries.

Caution: Battery may be harmful if swallowed.

PACKAGE DESIGN ©1997: MILLENIUM EXPRESSIONS, INC.
DISTRIBUTOR: MILLENIUM EXPRESSIONS, INC.
NEW YORK, NEW YORK 10001
E-MAIL: MillenX@aol.com